

SCROLL SHUTTER DOG WITH LAG 88-254PC




John Wright Company
P.O. Box 269
Wrightsville, PA 17368
1-800-444-9364
www.jwright.com



Shutter dogs or tiebacks are a traditional way to hold shutters open.

John Wright combines modern high-quality finishes with the strength and traditional look and feel of cast iron. Shutter dogs or tiebacks are used to hold shutters in the open position. Dogs have a through-hole and are mounted so that they can be rotated to move out of the way of the shutter as it opens. The dog is then rotated in front of the open shutter to keep it open. Dogs are installed at the far edge of the shutter when it is open and are weighted so that gravity keeps them in place.



- Sold in pairs and include lag screws for mounting
- Lag screw allows for adjustment range of up to 2 inches.
- Material: cast iron dog, 3/16" thick, with steel lag screw, washer, and retainer clip
- Finish: WeatherWright™ coating process. This multi-step coating provides long life in outdoor environments while offering excellent value. It including both zinc electroplating and black-matte TGIC powder coating. Zinc plating provides far more protection than powder coating alone. The zinc layer is not only abrasion resistant but offers cathodic protection to small areas of powder coating that may be accidentally damaged during installation. Tested to withstand a minimum of 144 hours of salt spray with no visible red-rust corrosion. All fasteners and hardware meet this same standard.
- Warranty: 1-year replacement
- Optional and related items:
 - #88-439 Magnetic Shutter Dog Holder prevents rattling in windy conditions
 - Lag shield anchor (available from most local hardware stores) allows mounting into masonry surfaces

Installation

1. Open the shutter and position the shutter dog with the hole just below the bottom outside corner of the shutter. Dogs are left- and right-handed and have a top and bottom. The shorter half of the scroll must face up with the tip of the scroll closer to

the center of the window. Mark the position of the hole on the building. Make sure the shutter is close enough to the building to allow the lag screw to be installed at least 1.5 inches deep.

2. Move the shutter out of the way. If installing into wood, drill a 9/32" pilot hole. If installing into masonry, a lag shield anchor (not included) is required. Insert the lag screw through the hole in the dog and then slide the washer onto the lag and up against the back of the dog. Install the hairpin retaining clip through the hole in the lag. Partially install the lag and then move the shutter back into the open position. Tighten the lag until the shutter is held in the desired position with modest pressure. Do not over tighten and make sure lag is installed at least 1.5 inches deep.

Contents and Dimensions

- (1) right-handed dog
- (1) left-handed dog
- (2) 3/8" diameter by 4.5" long lag screws
- (2) washers
- (2) hairpin clips

